




X ← Y ↓ Z



picture only from the left side of the vehicle

General Main Locations

? ? AIRB ???? ?? Airbag
? ? ABSE ???? ?? Airbag Sensor

Frontal Airbags

? ? KNBO ???? AF Knee Bolster Airbag
? ? KNBO ???? GF Knee Bolster Generator
? ? SEBA ???? AF Seat Back Knee Airbag
? ? SEBA ???? GF Seat Back Knee Generator
? ? FOWE ???? AF Footwell Airbag
? ? FOWE ???? GF Footwell Generator

Side Airbags


? ? DOOR ???? AS Door Side Airbag
? ? DOOR ???? GS Door Side Generator

Head Airbags

? ? DOOR ???? AH Door Head Airbag
? ? DOOR ???? GH Door Head Generator
? ? ROFR ???? AH Roof Frame Head Airbag
? ? ROFR ???? GH Roof Frame Head Generator

Interaction Airbags (without picture)

? 2 AIRB ???? AI Interaction Airbag frontal
? 2 AIRB ???? GI Interaction Generator frontal
? 5 AIRB ???? AI Interaction Airbag rear
? 5 AIRB ???? GI Interaction Generator rear



Frontal Airbags

? ? STWL ???? AF Steering Wheel Airbag
 ? ? STWL ???? GF Steering Wheel Gen.
 ? ? DASB ???? AF Dashboard Airbag
 ? ? DASB ???? GF Dashboard Generator

Pedestrian Airbags

? 2 BUMP ???? AP Bumper Airbag
 ? 2 BUMP ???? GP Bumper Generator
 ? 2 HOOD ???? AP Hood Airbag
 ? 2 HOOD ???? GP Hood Generator

Frontal Airbags

? ? SEBE ???? AF Seat Belt Airbag
 ? ? SEBE ???? GF Seat Belt Generator

Side Airbags

? ? SEPN ???? AS Seat Pan Airbag
 ? ? SEPN ???? GS Seat Pan Generator
 ? ? SEBA ???? AS Seat Back Airbag
 ? ? SEBA ???? GS Seat Back Generator

Rear Airbags

? ? HERE ???? AR Head Restraint Airbag
 ? ? HERE ???? GR Head Restraint Gen.