

picture only from the left side of the vehicle

General Main Locations

?? AIRB	???? ??	Airbag
?? ABSE	???? ??	Airbag Sensor

Frontal Airbags

?? KNBO	???? AF	Knee Bolster Airbag
?? KNBO	???? GF	Knee Bolster Generator
?? SEBA	???? AF	Seat Back Knee Airbag
?? SEBA	???? GF	Seat Back Knee Generator
?? FOWE	???? AF	Footwell Airbag
?? FOWE	???? GF	Footwell Generator

Side Airbags


?? DOOR	???? AS	Door Side Airbag
?? DOOR	???? GS	Door Side Generator

Head Airbags

?? DOOR	???? AH	Door Head Airbag
?? DOOR	???? GH	Door Head Generator
?? ROFR	???? AH	Roof Frame Head Airbag
?? ROFR	???? GH	Roof Frame Head Generator

Interaction Airbags (without picture)

?? AIRB	???? AI	Interaction Airbag
?? AIRB	???? GI	Interaction Generator



Frontal Airbags

?? STWL ???? AF Steering Wheel Airbag
?? STWL ???? GF Steering Wheel Gen.
?? DASB ???? AF Dashboard Airbag
?? DASB ???? GF Dashboard Generator

Pedestrian Airbags

?? 2 BUMP ???? AP Bumper Airbag
?? 2 BUMP ???? GP Bumper Generator
?? 2 HOOD ???? AP Hood Airbag
?? 2 HOOD ???? GP Hood Generator

Frontal Airbags

?? SEBE ???? AF Seat Belt Airbag
?? SEBE ???? GF Seat Belt Generator

Side Airbags

?? SEPN ???? AS Seat Pan Airbag
?? SEPN ???? GS Seat Pan Generator
?? SEBA ???? AS Seat Back Airbag
?? SEBA ???? GS Seat Back Generator

Rear Airbags

?? HERE ???? AR Head Restraint Airbag
?? HERE ???? GR Head Restraint Gen.