Additional Instrumentation - Head, Torso and Pelvis



Head - AC
HEAD LE 00 HF AC X, -Y, -Z
HEAD RI 00 HF AC X, -Y, -Z
HEAD UP 00 HF AC X, -Y, -Z
HEAD FR 00 HF AC X, -Y, -Z
HEAD RE 00 HF AC X, -Y, -Z

Head - AV
HEAD 00 00 HF AV X, -Y, -Z

Chest - AV
CHST 00 00 H3 AV X, -Y, -Z

Clavicle Right - FO
CLAV RI 00 HF FO X, -Z

Clavicle Left - FO
CLAV LE 00 HF FO X, -Z

Ribs Right - FO/ MO
RIBS RI 01 HF FO X, -Y, -Z
RIBS RI 01 HF MO Z
...
RIBS RI 06 HF FO X, -Y, -Z
RIBS RI 06 HF MO Z

Ribs Left - FO/ MO
RIBS LE 01 HF FO X, -Y, -Z
RIBS LE 01 HF MO Z
...
RIBS LE 06 HF FO X, -Y, -Z
RIBS LE 06 HF MO Z

Iliac - FO/MO
ILAC RI 00 HF FO X
ILAC RI 00 HF MO Y

Iliac - FO/MO
ILAC RI 00 HF FO X
ILAC RI 00 HF MO Y

Submarining Right - FO
SUMA RI UP HF FO X
SUMA RI LO HF FO X

Submarining Left - FO
SUMA LE UP HF FO X
SUMA LE LO HF FO X

Pelvis- AV
PELV 00 00 HF AV X, -Y, -Z