


Frontal Impact

Note that sensor configuration is different for side impact.
 ISO Codes used must reflect the chosen orientation.

Left-hand side impact: SHLD LE 00 QA FO X, -Y, -Z, CHST LE UP QA DC 0, CHST LE UP QA VO 0, CHST LE LO QA DC 0, CHST LE LO QA VO 0, CHST LE UP QAAN Z and CHST LE LO QAAN Z.

Right-hand side impact: SHLD RI 00 QA FO X, -Y, -Z, CHST RI UP QA DC 0, CHST RI UP QA VO 0, CHST RI LO QA DC 0, CHST RI LO QA VO 0, CHST RI UP QAAN Z and CHST RI LO QAAN Z.

Note that the IR-TRACC device fitted to this dummy records a voltage.
 It is more normal to exchange the distance channel, IR-TRACC total length.



Frontal Impact

 Note that sensor orientation is different for side impact configurations.
 ISO Codes used must reflect the chosen orientation.
 Left-hand side impact: TRRI LE UP QA AC Y and TRRI LE LO QA AC Y.
 Right-hand side impact: TRRI RI UP QA AC Y and TRRI RI LO QA AC Y.

