



Extension of the MME Data Format for nonlinear transducers

P. Derpmann-Hagenström, Dr. D. Grabowski

Transfer function – Motivation

For the computing of the physical units from the transducer output transfer functions are necessary.

For a long time only linear regression has been used.

Some years ago the calibration of chest deflection potentiometers for the Hybrid III family has to be done with a 3rd order polynomial regression for special tests.

The MME format supports this situation since version 1.6 with a few new descriptors in the channel header. The exchanged values are linear calibrated but with these additional descriptors the polynomial calibrated values can be derived.

A new situation arises with the nonlinear transducers of the IR-TRACC, which needs a complete revision of the MME channel handling.

On the following pages we want to introduce a system of descriptors covering the needs of all known use cases and giving flexibility for future developments.

Description of coefficients

Since nonlinear transducers normally do not allow conventional scaling of the output values by the supply voltage – they have intrinsic supply regulators – the description of the transfer function coefficients does not contain any reference to supply voltage.

Furthermore, we consider digital sensors, too. Therefore we describe the transfer functions using **physical units** (short “unit” e.g. “g”, ...) and **electrical units** (short “EU” e.g. “mV”, “LSB”).

Example: linear inverse sensitivity b in “g/mV” or “g/LSB”

The following five use cases have to be considered:

Transfer function - Use cases

1) Linear transducer with relative measurement *Standard for most transducers*

$$D = b \cdot S$$

	Description	Unit	Descriptor	Example Value
S	sensor output reading	[EU]	-	-
D	physical value	[Unit]	-	Values of Sample
b	inverse sensitivity	[Unit/EU]	Inverse sensitivity	5.070000E-003
			.Transfer function used	Linear regression
			.Direction polarity	+
		[EU]	Offset pre test	0.01
		[Unit]	Offset post test	NOVALUE
	Sensitivity	[EU/Unit]	.Sensitivity¹⁾	197.2

¹⁾ must not be used if *Inverse sensitivity* is missing or NOVALUE

Transfer function - Use cases

2) Linear transducer with relative measurement and additional polynomial calibration e.g. Chest Deflection of H3 Dummy

$$D = b \cdot S \quad \text{and} \quad D = M + C \cdot S + B \cdot S^2 + A \cdot S^3$$

	Description	Unit	Descriptor	Example Value
S	sensor output reading	[EU]	-	-
D	physical value	[Unit]	-	Values of Sample
b	inverse sensitivity	[Unit/EU]	Inverse sensitivity	5.070000E-003
A	polynomial coefficient (cubic)	[Unit/(EU)^3]	Inverse polynom coeff A	-1.0951781374E-12
B	polynomial coefficient (quadratic)	[Unit/(EU)^2]	Inverse polynom coeff B	4.6327907808E-8
C	polynomial coefficient (linear)	[Unit/(EU)^1]	Inverse polynom coeff C	4.7696179329E-3
M	polynomial coefficient (constant)	[Unit]	Inverse polynom coeff M	-1.1143570169E+0
			.Transfer function used	Linear regression
			.Direction polarity	+
		[EU]	Offset pre test	0.01
		[Unit]	Offset post test	NOVALUE
	Sensitivity	[EU/Unit]	.Sensitivity ¹⁾	197.2

¹⁾ must not be used if Inverse sensitivity is missing or NOVALUE



Transfer function - Use cases

3) Linear transducer with absolute measurement

e.g. Angular transducer in the 2D/3D IR-TRACC, absolute pressure

$$D = b \cdot (S - S_{Cal}) = M + C \cdot S$$

	Description	Unit	Descriptor	Example Value
S	sensor output reading	[EU]	-	-
D	physical value	[Unit]	-	Values of Sample
A	polynomial coefficient (cubic)	[Unit/(EU)^3]	Inverse polynom coeff A	0
B	polynomial coefficient (quadratic)	[Unit/(EU)^2]	Inverse polynom coeff B	0
C	polynomial coefficient (linear)	[Unit/(EU)^1]	Inverse polynom coeff C	4.7696179329E-3
M	polynomial coefficient (constant)	[Unit]	Inverse polynom coeff M	-1.1143570169E+0
			.Transfer function used	Linear regression with offset
			.Direction polarity	+
	Must not be used!	[EU]	Offset pre test	NOVALUE
		[Unit]	Offset post test	NOVALUE

Transfer function - Use cases

4) Nonlinear transducer with relative measurement and polynomial approximation
e.g. *polynomial calibrated belt force*

$$D = M + C \cdot S + B \cdot S^2 + A \cdot S^3$$

	Description	Unit	Descriptor	Example Value
S	sensor output reading	[EU]	-	-
D	physical value	[Unit]	-	values of sample
A	polynomial coefficient (cubic)	[Unit/(EU)^3]	Inverse polynom coeff A	-1.0951781374E-12
B	polynomial coefficient (quadratic)	[Unit/(EU)^2]	Inverse polynom coeff B	4.6327907808E-8
C	polynomial coefficient (linear)	[Unit/(EU)^1]	Inverse polynom coeff C	4.7696179329E-3
M	polynomial coefficient (constant)	[Unit]	Inverse polynom coeff M	-1.1143570169E+0
			.Transfer function used	Polynomial regression 3rd order
			.Direction polarity	+
	Must not be used!	[EU]	Offset pre test	NOVALUE
		[Unit]	Offset post test	NOVALUE

Transfer function - Use cases

5) Nonlinear transducer with power function approximation

e.g. *Displacement transducer in the IR-TRACC*

$$D = \xi_1 \cdot (S + S_0)^\alpha + \xi_0 = \xi_1 \cdot \exp(\alpha \cdot \log(S + S_0)) + \xi_0$$

	Description	Unit	Descriptor	Example Value
S	sensor output reading	[EU]	-	-
D	physical value	[Unit]	-	Values of Sample
ξ_0	power function engineering offset	[Unit]	.Power func eng offset	12.4
ξ_1	power function sensitivity	[Unit/(EU)]	.Power func sensitivity	.767
α	power function exponent	[1]	.Power func exponent	-0.5
S_0	power function electrical offset	[EU]	.Power func electr offset	0.9
			.Transfer function used	Power function
			.Direction polarity	+
Must not be used!		[EU]	Offset pre test	NOVALUE
		[Unit]	Offset post test	NOVALUE

Transfer function – Existing and new Parameters

Descriptor	Values	Status	Remark
.Transfer function used	Linear regression Linear regression with offset Polynomial regression 3rd order Power function	new	The transfer function used for the computing of the physical units <i>Linear regression</i> is the default
.Direction polarity	+	new	Polarity of the sensor mounting orientation
-			
Inverse sensitivity	float	since 1.6	Inverse sensitivity (Linear regression)
Inverse polynom coeff A	float	since 1.6	3 rd order polynomial - cubic part
Inverse polynom coeff B	float	since 1.6	3 rd order polynomial - quadratic part
Inverse polynom coeff C	float	since 1.6	3 rd order polynomial - linear part
Inverse polynom coeff M	float	since 1.6	3 rd order polynomial - constant part
Offset pre test	float	since 1.6	Electrical offset short before the test
Offset post test	float	since 1.6	Physical offset after the test
.Power func eng offset	float	new	Power function - physical offset
.Power func sensitivity	float	new	Power function - sensitivity
.Power func electr offset	float	new	Power function – electrical offset
.Power func exponent	float	new	Power function – exponent α
.Sensitivity ¹⁾	float	new	Sensitivity (for Linear regression only)

¹⁾ must not be used if *Inverse sensitivity* is missing or NOVALUE

Transfer function - Usage

- Transfer functions and their parameters are only reasonable for transducer channels
- Computing of the output quantity has to be done in the test execution software
- Computing of calculated or derived channels has to be done in the test analysis software
- Storage of the transfer function, its parameters and the sensor polarity should be done in the channel file header
- *Offset pre test* [EU] is only necessary, when it is required by the measurement chain
- *Offset post test* [Unit] is the value which is used for the physical offset correction within [*Start offset interval*, *End offset interval*]
- For transducer channels with transfer functions other than *Linear regression* the physical offset at the start of the test is important. This comes into conflict with the need of offset correction for the data exchange.
All these channels have to be exchanged without offset correction