


## ISO codes for pulltest

### ECE R 14 / FMVSS210

point of application	<b>N</b>
sensor location	cylinder of pull machine
dimension	force
	displacement


	ISO code	main location
<b>1</b>	T?TDSB000000FOX?	traction device shoulder belt
<b>1</b>	T?TDSB000000DSX?	traction device shoulder belt
<b>2</b>	T?TDLB000000FOX?	traction device lap belt
<b>2</b>	T?TDLB000000DSX?	traction device lap belt
<b>3</b>	T? <b>TDCG</b> 000000FOX?	traction device <b>center of gravity</b>
<b>3</b>	T? <b>TDCG</b> 000000DSX?	traction device <b>center of gravity</b>



**ISO codes for pulltest**  
**ECE R 14 / FMVSS210**

point of application	<b>N</b>
sensor location	cylinder of pull machine
dimension	force displacement

	ISO code	main location
<b>1</b>	T?TDSB000000FOX?	traction device shoulder belt
<b>1</b>	T?TDSB000000DSX?	traction device shoulder belt
<b>2</b>	T?TDLB000000FOX?	traction device lap belt
<b>2</b>	T?TDLB000000DSX?	traction device lap belt
<b>3</b>	T? <b>TDCG</b> 000000FOX?	traction device <b>center of gravity</b>
<b>3</b>	T? <b>TDCG</b> 000000DSX?	traction device <b>center of gravity</b>
<b>4</b>	T? <b>TDCG</b> 000000FOX?	traction device <b>center of gravity</b>
<b>4</b>	T? <b>TDCG</b> 000000DSX?	traction device <b>center of gravity</b>



**For the center of gravity of the 60% part always use the outer position number**

**ISO codes for pulltest**  
**ISOFIX ECE R14**

	point of application	<b>N</b>
	sensor location	cylinder of pull machine
	dimension	force
		displacement


	ISO code	main location
<b>1</b>	T?SFAD000000FOX?	Static Force Application Device
<b>1</b>	T?SFAD000000DSX?	Static Force Application Device



**ISO codes for pulltest  
top tether pull / ADR34**

	point of application	<b>N</b>
	sensor location	cylinder of pull machine
	dimension	force
		displacement

	ISO code	main location
<b>1</b>	T?TOPT000000FOX?	top tether
<b>1</b>	T?TOPT000000DSX?	top tether
<b>2</b>	T? <b>TDCG</b> 000000FOX?	traction device <b>center of gravity</b>
<b>2</b>	T? <b>TDCG</b> 000000DSX?	traction device <b>center of gravity</b>



**For the center of gravity of the 60% part always use the outer position number**

**ISO codes for pulltest  
head restraint ECE R17**

	point of application	<b>N</b>
	sensor location	
	dimension	force
		displacement
		moment (calculated)
		angle

	ISO code	main location
<b>1</b>	T?HEADHH0000FOX?	head
<b>1</b>	T?HEADHH0000DSX?	head
<b>2</b>	T? <b>BAPN</b> ??0000FOX?	<b>(SAE) back pan</b>
<b>2</b>	T? <b>BAPN</b> ??0000MOX?	<b>(SAE) back pan</b>
		<b>in the ECE R17 it's called SAE back pan</b>

